



Dry Vacuum Pumps

nXR30i, nXR40i, nXR60i, nXR90i and nXR120i

INSTRUCTION MANUAL

Copyright notice

©Edwards Limited 2022. All rights reserved.

Trademark credit

Edwards and the Edwards logo are trademarks of Edwards Limited, Innovation Drive, Burgess Hill, West Sussex RH15 9TW.

Disclaimer

The content of this manual may change from time to time without notice. We accept no liability for any errors that may appear in this manual nor do we make any expressed or implied warranties regarding the content. As far as practical we have ensured that the products have been designed and constructed to be safe and without risks when properly installed and used in accordance with their operating instructions.

We accept no liability for loss of profit, loss of market or any other indirect or consequential loss whatsoever.

Product warranty and limit of liability are dealt with in our standard terms and conditions of sale or negotiated contract under which this document is supplied.

You must use this product as described in this manual. Read the manual before you install, operate, or maintain the product.

Contents

1. Safety and compliance.	6
1.1 Definition of Warnings and Cautions.	6
1.2 Safety symbols.	7
2. General description.	8
2.1 Overview.	8
2.2 Pump controller.	10
2.3 Interface control panel.	10
2.3.1 Auxiliary connector socket.	10
2.4 Logic interface.	11
2.5 Auto-run.	12
2.6 Pump controller configuration.	12
3. Technical data.	13
3.1 Operating and storage conditions.	13
3.2 Performance.	14
3.3 Materials exposed to gases pumped.	17
3.4 Electrical data.	17
4. Installation.	19
4.1 Installation safety.	19
4.2 Unpack and inspect.	19
4.3 Mechanical installation.	20
4.4 Leak test the system.	22
4.5 Electrical installation.	22
4.5.1 Pump voltage setting.	23
4.5.2 Connect the electrical supply.	24
4.6 Connection for remote control and monitoring.	24
5. Commission the pump.	25
6. Operation.	26
6.1 Operation safety.	26
6.2 Operational modes.	27
6.2.1 Manual control mode.	27
6.3 Logic interface data.	29
6.4 Parallel control and monitoring.	31
6.5 Analogue speed control.	32
6.6 Hardware configuration.	34
6.7 Operational modes.	34

6.8 Start the pump.	34
6.9 Shut down the pump.	35
6.10 Restart the pump.	35
6.11 Unplanned shutdown.	36
6.12 Gas ballast operation.	36
6.13 Gas ballast adaptor fit.	37
6.14 Extra silencer removal.	37
6.15 Mounting kit use.	37
7. Maintenance and service.	39
7.1 General maintenance.	39
7.2 Maintenance plan.	39
7.3 Inspect and clean the inlet strainer.	39
7.4 Clean the external fan grill.	40
7.5 Replace the pump bearings.	40
7.6 Replace the pump controller.	40
7.7 Electrical safety check.	40
7.8 Service indicator codes.	40
7.9 Service.	41
7.9.1 Return the equipment or components for service	41
8. Fault finding.	42
8.1 Alarm indicator codes.	43
9. Storage.	45
10. Disposal.	46
11. Accessories.	47
11.1 Electrical cables.	47
11.2 Gas ballast adaptor.	48
11.3 Gas ballast blank adaptor.	48
11.4 Valves.	48
11.5 Mounting kit.	48

List of Figures

Figure 1: Pump features.	9
Figure 2: Interface panel.	10
Figure 3: Valve connector.	11
Figure 4: Dimensions.	14
Figure 5: nXR120i application guidelines for chamber pump-down.	15
Figure 6: nXR30i performance curve.	16
Figure 7: nXR40i performance curve.	16
Figure 8: nXR60i performance curve.	16
Figure 9: nXR90i performance curve.	17
Figure 10: nXR120i performance curve.	17
Figure 11: Speed vs Power graph.	18
Figure 12: Voltage selection plate.	23
Figure 13: Logic interface connections - parallel control.	32
Figure 14: Logic interface connections - analogue speed control.	33
Figure 15: Analogue speed control.	33
Figure 16: Gas ballast open-close.	36

1. Safety and compliance

1.1 Definition of Warnings and Cautions

NOTICE:



For safe operation from the start, read these instructions carefully before you install or commission the equipment and keep them safe for future use.

Read all the safety instructions in this section and the rest of this manual carefully and make sure that you obey these instructions. The equipment must only be operated and maintained by trained personnel in the proper condition and as described in this instruction manual.

Obey local and state requirements and regulations. If you have any questions about safety, operation or maintenance of the device, please contact our nearest subsidiary.

Important safety information is highlighted as warning and caution instructions. Obey these instructions.



WARNING:

If you do not obey a warning, there is a risk of injury or death. Different symbols are used according to the type of hazard.



CAUTION:

If you do not obey a caution, there is a risk of minor injury, damage to equipment, related equipment or process.



NOTICE:

Information about properties or instructions for an action which, if ignored, will cause damage to the equipment.







We reserve the right to change the design and the stated data. The illustrations are not binding.

Keep the instructions for future use.

1.2 Safety symbols

The safety symbols on the products show the areas where care and attention is necessary.

The safety symbols that we use on the product or in the product documentation have the following meanings:

	<p>Warning/Caution</p> <p>An appropriate safety instruction must be followed or caution to a potential hazard exists.</p>
	<p>Warning - Heavy object</p> <p>Identifies a possible hazard from a heavy object.</p>
	<p>Warning - Dangerous voltage</p> <p>Identifies possible hazards from hazardous voltages.</p>
	<p>Warning - Protective earth (ground)</p> <p>Earth point for electrical equipment.</p>
	<p>WEEE symbol</p> <p>The equipment must be discarded carefully. Obey local and national regulations for disposal of this equipment.</p>
	<p>Warning - Use protective equipment</p> <p>Use appropriate protective equipment for the task.</p>

2. General description

2.1 Overview



WARNING: INCORRECT USE OF EQUIPMENT

Risk of injury or damage to the equipment. Incorrect use of the equipment can cause damage to the equipment or injury to people. The user is responsible for the safe operation, installation and monitoring of the system.



CAUTION: GAS BALLAST INSTALLATION

Risk of damage to the equipment. If water vapor is present within the system, or is pumped by the product the gas ballast must be used to prevent damage to the product. The gas ballast should continue to be applied with the pump running, for at least 1 hour after the water vapor source has been removed to enable the pump to dry.

The nXRi product family is a range of dry, multi-stage roots vacuum pumps that offers high pumping speed in a compact form. The pump is connected by a power cord and is designed for use on clean duty applications.

The cord ratings are:

Supply voltage (V)	Current (A)	Frequency (Hz)
100 - 127	14	50 or 60
200 - 240	7	

The pump is not designed for use with flammable, corrosive, toxic or other hazardous gases. Gas or oxygen can mix in the pump system.

The dry pumping system can be used in either transient or steady state gas load conditions. The pump can sustain continuous operation with a maximum power consumption of 850 W. When the load is more than 850 W motor power the speed temporarily reduces. When high load passes the motor speed is increased, or when the transient overload protection has recovered. Refer to [Table: Performance data](#) for information on maximum inlet pressure.

Refer to [Figure: nXRi pumps](#), the system is supplied with either a NW25, NW40 inlet port (1) and a NW25 exhaust port (10).

The pump mechanism is operated by an electric motor driven by an internal pump controller. The rotational elements of the pumping mechanism are simply supported at the end by lubricated bearings. PFPE lubricant is used and this is contained in both the gearbox and motor ends of the pump module, these are "sealed for life" and the lubricant does not need to be replaced until the pump service interval is reached.

The system is air cooled by a fan installed internally in the pump enclosure. The pump has a thermal protection device that will stop the motor if a thermal overload, for example in high ambient temperature occurs. You must restart the pump after the pump is cooled down.

The pump is designed to pump the residual gases used in high vacuum systems. The gases are:


- Air
- Oxygen (O₂) < 21% by volume
- Nitrogen
- Krypton
- Argon
- Helium

You can use the pump to pump water vapour. You must use the gas ballast when water vapour is pumped. The water vapour must not condense in the pump.

Refer to [Performance data](#).

To use the pump for a gas that is not listed, contact the supplier for advice. Failure to contact the supplier can invalidate the warranty of the pump. Do not use the pump for aggressive or corrosive gases.

Figure 1 Pump features



1. Inlet port
2. Control dashboard
3. Gas ballast
4. Vibration isolators
5. Castors x 2
6. 15-way D-type connector
7. Auxiliary connector
8. Mains circuit breaker
9. Mains connector port
10. Exhaust port
11. Protective earth stud
12. Voltage selection switch (under cover)
13. Lifting eye positions

2.2 Pump controller


The pump controller contains the drive electronics to controls the pump operation. The pump controller controls the supply of electric current to the motor as per the operating conditions.

The interface control panel is installed on the pump controller. The pump can be operated:

- manually, with the buttons on the user interface control panel. Refer to [Figure: Interface control panel](#).
- remotely, with the serial communications or digital and analogue process control (parallel), through the 15-way D-type interface connector. Refer to [Connection for remote control and monitoring](#) on page 24.

2.3 Interface control panel

Figure 2 Interface panel



1. Start button
2. Sleep button*
3. Standby increase button
4. Standby decrease button
5. Alarm indicator LED
6. Service indicator LED
7. Auto-run indicator LED
8. Standby decrease indicator LED
9. USB port (not for operation)
10. Standby increase indicator LED
11. Standby indicator LED
12. Run indicator LED
13. Stop button
14. Power status LED

* Enables STANDBY functionality

2.3.1 Auxiliary connector socket


An auxiliary control connection on the rear panel controls an optional inlet valve. This inlet valve can be operated in parallel with the normal pump output signal. Refer to [Figure: Pump features](#), (7). The valve is usually closed and:

- will open when the normal signal becomes active (pump at speed)
- will close when you select the stop button or if there is a fault condition

The reaction time will be in line with the valve selection and the output signal is 24 V d.c. Refer to [Figure: Valve connector](#) for polarity of the connector pins when the connector is energized.

The auxiliary connector is regulated to 24 V d.c. to control the accessories. If the auxiliary load current exceeds the value in [Table: Auxiliary load currents](#), the output will shut down to protect the pump controller. Refer to [Table: Recommended mating plugs](#) for the recommended mating plugs.

Figure 3 Valve connector



Pin number	Signal	Polarity
1	Valve 1 - Control output	Positive
2	Valve 2 - Control output	Positive
3	Valve 1 - Return	Negative
4	Valve 2 - Return	Negative

Table 1 Auxiliary load currents

Description	Data
Connector plug	Phoenix part number SACC-DSI-M 8FS-4CON-M12/0.5
Voltage output	24 V d.c. -25%, +10% (18 V d.c. to 26.4 V d.c.)
Output power	2 Channels with 4 watts per channel

Table 2 Recommended mating cable

Mating connector cable	Phoenix part number
Screw connection, straight	SACC-M 8MS-4CON-M-SW
Solder connection, straight	SACC-M 8MS-4CON-M
Screw connection, right angle	SACC-M 8MR-4CON-M-SW
Solder connection, right angle	SACC-M 8MR-4CON-M

2.4 Logic interface

The logic interface is designed to support the serial control, the parallel control, monitor and operate through one connector.

The pump controller can be operated through the 15-way D-type logic interface connector. The signals on the logic interface are:

- control inputs: switch type and analogue signals that controls the pump.
- status outputs: to identify the status of the system Tab.

For serial control select RS232 or RS485. Refer to Serial Comms Interface manual.

For control modes refer to [Table: Manual control mode](#).

For logic interface data refer to [Logic interface data](#) on page 29.

2.5 Auto-run

The auto-run setting configures the pump to start automatically when the power is switched on, without any customer intervention.

You can configure the auto-run through serial communications, or with the start or stop button. Push and hold the start or stop button for more than eight seconds to enable or disable the auto-run setting. The auto-run LED displays the auto-run setting.

The pump can be stopped by either manual, parallel or serial control modes when in auto-run mode.

Note:

Refer to [Operation safety](#) on page 26 for guidelines on how to configure different operational modes and any associated earnings to consider.

2.6 Pump controller configuration

The integral pump controller monitors the power and temperature of the pump. The pump controller protects the user and the pump when the pump is operated under sustained high load or in fault conditions.

The pump controller has the interface control panel and the pump can be operated:

- manually, with the buttons on the user interface control panel. Refer to [Figure: Interface control panel](#).
- remotely, through serial communications or digital and analogue process control (parallel), via the 15-way D-type interface connector. Refer to [Connection for remote control and monitoring](#) on page 24.

3. Technical data

3.1 Operating and storage conditions

Table 3 Operating and storage conditions

Range	Data
Ambient operating temperature range	5 °C to 40 °C
Ambient operating humidity range	80% up to 31 °C Reducing linearly to 50% at 40 °C
Maximum operating altitude	3000 m
Ambient storage temperature range	-30 °C to 70 °C
Maximum humidity (storage in original packaging)	≤ 95 % RH
Equipment type	Indoor use
Enclosure protection (tested according to IEC 60529)	IP21
Enclosure protection (tested according to UL50e and CSA C22.2 No. 94.2)	NEMA 1

Table 4 Environmental conditions

Pollution	Pollution degree 2
Installation	Installation category II
Altitude restriction	Maximum 3000 m
Area of use	Indoor

Table 5 Mechanical data

Parameter	nXR30i	nXR40i	nXR60i	nXR90i	nXR120i
Mass	27.6 kg		29.6 kg		30 kg
Inlet connection	NW25		NW40		
Overall dimensions (L x W x H)	478x217x301		494 x 217 x 301 mm		
Maximum tilt angle for operation	± 5°				
Maximum tilt angle for transport	30°				
Nominal rotational speed	15000 rpm				
Outlet connection	NW25				

Figure 4 Dimensions




Table 6 Dimensions

Type	Variable dimensions							
	A		B		C		D	
	mm	inch	mm	inch	mm	inch	mm	inch
nXR30/40i	478	18.82	443	17.44	103	4.06	339	13.34
nXR60/90/120i	494	19.45	461	18.15	107	4.21	370	14.56

3.2 Performance

Table 7 Performance data

Parameter	Units	nXR30i	nXR40i	nXR60i	nXR90i	nXR120i
Maximum pumping speed *	m ³ /hr	30	40	60	90	120
Ultimate pressure	mbar	0.03				
Maximum continuous inlet pressure	mbar	1013				20
Maximum continuous exhaust pressure	mbar(g)	200				
Suck-back protection		Exhaust valve design				
Maximum pressure rise when stopped, no inlet flow or gas ballast flow	mbar	100				
Maximum permitted gas ballast inlet pressure (with gas ballast adaptor fitted)	bar(g)	0.5				
Gas ballast flow	l/min	25				
Maximum water vapor pumping rate (with gas ballast applied)	kg/hr	0.3				
Typical ultimate pressure with gas ballast	mbar	< 0.1				
Leak tightness (static)	mbar l/s	< 1x10 ⁻⁶				

* Values for maximum pumping speed are obtained with the inlet strainer. The pumping speed is measured at standard ambient temperature and pressure. At higher temperature or different ambient pressures pump performance may be compromised and the rotational speed may drop below nominal.

Note:

For the nXR120i, the pump may thermally protect itself and shut down, if:

1) the continuous operating pressure at the inlet is greater than 20 mbar

2) the nXR120i is used to evacuate large chambers, particularly if large continuous gas loads are combined with the chamber pump-down, [Table: nXR120i application guidelines for chamber pump-down](#) provides guidelines on the acceptable application parameters. It is also advised to start chamber evacuation with the pump at rest than with the pump already operating at full rotational speed.

Figure 5 nXR120i application guidelines for chamber pump-down





Table 8 Sound data


Declared dual-number noise emission values in accordance with ISO 4871					
	nXR30i	nXR40i	nXR60i	nXR90i	nXR120i
Measured A-weighted emission sound pressure level, L_{pA} at ultimate vacuum 1 m from the pump in free space	55.0 dB(A)				
Measured A-weighted emission sound pressure level, L_{pA} at 15 mbar at inlet 1 m from the pump in free space	57.0 dB(A)				
Uncertainty, K_{pA}	2.5 dB(A)				
Product tested to ISO standard 3744:2010					

Figure 6 nXR30i performance curve




- 1. Pumping speed with gas ballast
- 2. Pumping speed without gas ballast
- 3. Power with gas ballast
- 4. Power without gas ballast

Figure 7 nXR40i performance curve




- 1. Pumping speed with gas ballast
- 2. Pumping speed without gas ballast
- 3. Power with gas ballast
- 4. Power without gas ballast

Figure 8 nXR60i performance curve




- 1. Pumping speed with gas ballast
- 2. Pumping speed without gas ballast
- 3. Power with gas ballast
- 4. Power without gas ballast

Figure 9 nXR90i performance curve



- 1. Pumping speed with gas ballast
- 2. Pumping speed without gas ballast
- 3. Power with gas ballast
- 4. Power without gas ballast

Figure 10 nXR120i performance curve



- 1. Pumping speed with gas ballast
- 2. Pumping speed without gas ballast
- 3. Power with gas ballast
- 4. Power without gas ballast
- 5. Non-continuous speed with gas ballast
- 6. Non-continuous speed without gas ballast

3.3 Materials exposed to gases pumped

The materials and the components exposed to the gases in the pump are:

- Iron
- Aluminium alloy
- Steel
- Fluoroelastomer (seals)
- PFPE lubricant

3.4 Electrical data

If the pump is operating with a supply voltage below the nominal operating range, example < 200 V in high voltage regions or < 100 V in low voltage regions, the product will limit the maximum power deliverable to the pump motor. If the application load exceeds the maximum power available, pump rotational speed will be reduced. Refer to [Figure: Speed vs Power graph](#). At lower rotational speeds pumping performance will be

impaired, however the product can still pump down chambers or operate in steady state conditions.


Table 9 Electrical rating for continuous operation

Pump	Supply voltage (V a.c. rms)	Phase	Frequency (Hz)	Input current (A rms)
All variants	200 - 240 ± 10%	Single	50 or 60	7.0
	100 - 127 ± 10%	Single	50 or 60	14.0

Table 10 Recommended regional supply protection

Area	Voltage	Protection rating
UK	230 V	10 A, 250 V a.c. rms
Europe	230 V	10 A, 250 V a.c. rms
US	120 V	15 A, 250 V a.c. rms
Japan	100 V	15 A, 250 V a.c. rms

Figure 11 Speed vs Power graph



4. Installation

4.1 Installation safety



CAUTION: SAFETY INSTRUCTIONS

Follow all safety instructions and take note of all appropriate precautions.

Possible hazards on the dry pumping system include electricity, process chemicals, and Fomblin® (PFPE) oil:

- Refer to the safety manual P40040100 for safety information for the specification, design, operation and maintenance of vacuum pumps and vacuum systems. Contact us for the safety manual.
- Contact us or the local service centre for more information for advice or assistance on installation.
- Do not remove the temporary covers from the system inlet and exhaust until ready to connect.
- Do not operate the system unless the inlet and exhaust are connected to the vacuum and exhaust extraction system.
- Isolate the other components in the process system from the electrical supply to prevent accidental operation.
- Electrical supplies are potentially hazardous energy sources. Lockout and tagout before you do the maintenance.
- Obey all national and local rules and safety regulations when you install the system.
- Tighten the cables, hoses and pipework during installation to prevent a trip hazard.
- Make sure that the installation area is clean and free from debris and contamination before you install the pump.
- Make sure that all facilities given in this manual are available for the system to perform correctly.



WARNING: BLOCKED EXHAUST PIPELINE

Risk of damage to equipment. Make sure the exhaust pipeline is not blocked. If an exhaust isolation valve is used, make sure that the pump is not operated with the valve closed.

4.2 Unpack and inspect



WARNING: DAMAGED PUMP

Risk of injury to people or damage to equipment. Do not use the pump if it is damaged. Failure to do so can result in injury to people and/or damage to equipment.

**CAUTION: PUMP LIFE**

Risk of damage to equipment. Unpack the pump carefully and avoid excessive shock to the pump. Excessive shock will damage the bearings and reduce the life of the pump.

Refer to [Table: Mechanical data](#) for the mass of the pump.

The pump is supplied in a recyclable packaging.

1. Open the cardboard box from the top.
2. Remove the packing material. Keep all the packing materials for use in inspection and if the pump is returned for service.
3. Examine the pump for damage. If the pump is damaged, notify your supplier and the carrier immediately. Give the supplier and the carrier the information that follows:
 - part number of the pump
 - serial number of the pump
 - order number
 - supplier's invoice number
4. Do not use the pump if the pump is damaged.
5. If the pump is not to be used immediately, store the pump in the conditions given in [Storage](#) on page 45.
6. The pump is supplied with sealed inlets and outlet to prevent the entry of dust and vapor. Do not remove the seals until the pump is ready to be installed on the vacuum system.

4.3 Mechanical installation

**WARNING: HEAVY OBJECT**

Risk of physical injury. Use suitable equipment to lift the pump.

**WARNING: LOOSE CABLES/PIPEWORK**

Tripping hazard. Make sure that any cables and/or pipe work attached to the pump are fixed carefully to avoid a slip/trip hazard and to prevent any damage to the cable.

**WARNING: LIFTING EYE INTEGRITY**

Risk of injury or damage to equipment. Make sure that the maximum angle between the paired slings used to lift the system is 45 degrees. Increased angle could compromise the lifting eye integrity.

**WARNING: INSTALLATION SAFETY**

Risk of injury or damage to equipment. Install the pump in the vacuum system before you connect the pump to the power supply. This will make sure that the pump is not operated and injure people during installation.

**WARNING: STATIC PRESSURE**

Risk of damage to equipment. Do not step or stand on the pump, it is not designed to withstand large static loads.

**WARNING: HEAVY OBJECT**

Push-pull hazard with strain injury. Push or pull the pump system only for short distance and over flat surfaces. Lift the system if the floor is uneven or has obstacles.

**WARNING: EXHAUST BLOCKAGE**

Risk of injury or damage to equipment. A peak pressure of 3 bar(g) can be generated in the pump if the exhaust or pipework attached to the exhaust are blocked.

**CAUTION: INSTALLATION SAFETY**

Risk of injury or damage to the environment. Follow all local legislation when the pump is installed or removed to reduce the impact of the pump on the environment.

**CAUTION: CONDENSATE DRAINAGE**

Risk of damage to equipment. Use a catchpot to prevent the drainage of condensate back into the system. Condensate that drains back into the system could damage the pump.

Obey the instructions that follow when you install the pump:

- Make sure that there is no blockage to access the pump electrical supply cable or the other controls.
- Make sure that there is a minimum air gap of 100 mm on all sides of the pump to allow effective air circulation.
- Make sure that the system is on a firm and levelled surface that can support the mass of the pump.
- Make sure that the system is installed away from combustible materials.
- Level the pump to a maximum of 5 degrees (measured at the pump inlet).
- You must do a risk assessment of the location and make sure that you can move the pump safely and as per the local and national manual handling guidelines.

To move the pump:

1. Use suitable lifting equipment attached to lifting eyebolts (*Figure: nXRi pumps, (14)*) to move the dry pump system close to its final operating position. Refer to *Table: Mechanical data* for pump mass.

2. Secure the dry pump system with the rubber stand-off and two small castors (*Figure: nXRi pumps, (5)*).
3. Remove the plastic caps from the inlet and exhaust before you connect the pump to the vacuum system. Use appropriate NW vacuum fittings for connection to the system.

Obey the instructions that follows when you connect the pump to the vacuum system:

- Connect the pump to an exhaust line to minimize the noise and the exhaust emissions.
- Make sure that the pipeline connected to the pump inlet is as short as possible. Make sure that the pipeline has a minimum internal diameter to get maximum pump speeds.
- Put support under the vacuum pipeline to prevent the load on the coupling joints.
- Make sure that the pump exhaust line is not blocked as a pressure of 3 bar(g) can be generated in the exhaust pipework. Connect the pump with appropriate pipework and fittings.
- If necessary, install flexible bellows in the system pipelines to reduce the transmission of the vibration and to prevent the load on the coupling joints. The pressure rating of the bellows must be higher than the highest pressure generated in the system. We recommend that you use the manufacturer's bellows.
- If you use an exhaust extraction system make sure that it is appropriate for use with all pumped process gases. Make sure that the exhaust extraction system is not blocked or obstructed when the pump is in operation.

4.4 Leak test the system



CAUTION: SYSTEM LEAK TEST

Risk of injury or damage to equipment. Do the leak test of the system after installation. Seal all the leaks found to prevent leakage of dangerous substances out of the system and leakage of air into the system.

We will accept no liability or warranty claims for damages caused from flammable mixtures because of air leaks.

1. Do the leak test of the vacuum system after installation.
2. Seal all the leaks found.

4.5 Electrical installation



WARNING: ELECTRICAL CONNECTION

Risk of electric shock. The electrical installation must be done by a qualified person. Always make the electrical connections to the pump after the pump has been installed on the vacuum system.



WARNING: INSTALLATION SAFETY

Risk of electric shock or damage to equipment. The pump must be electrically installed in accordance with regional and local codes, and must obey the local and national safety requirements.



WARNING: HAZARDOUS VOLTAGE

Risk of electric shock or damage to equipment. The logic interface is 30 V maximum rated PELV and must only be connected to PELV interfaces. Failure to use an correctly rated supply could result in electric shock.

The pump is a cord-connected device and must be installed in accordance with local electrical regulations. Refer to [Table: Recommended cord sets](#).

The pump is supplied from a single phase 100 - 127 V a.c./200 - 240 V a.c. mains supply system. The branch circuit, supplying the pump, must be protected with a 10 A (200 - 240 V) or 15 A (100 - 127 V) branch circuit protection.



WARNING: ELECTRICAL CONNECTION

Risk of electric shock. Make sure that the pump is switched off and not connected to the electrical supply when you select the mains voltage.

4.5.1 Pump voltage setting


To set the correct voltage:

1. Isolate the pump from electrical supply.
2. Remove the screws on the voltage selection plate.
3. Rotate the voltage selection plate to point towards the required voltage setting (refer to [Figure: Voltage selection plate](#)).

The selector cover plate will make sure that the rocker switch below the plate is set to the correct voltage.

4. Make sure that the screws are tightened and the voltage selection plate is fully secured before you operate the pump.

Figure 12 Voltage selection plate



4.5.2 Connect the electrical supply



WARNING: PROTECTIVE EARTH CONNECTION

Risk of electric shock. Make sure that the pump and electrical cables are suitably protected against earth (ground) faults. We recommend you attach a protective earth (ground) conductor (with a cross sectional area of 2.5 mm²/14 AWG) to the protective earth (ground) stud.

Make the electrical connection to the pump mains connector port ([Figure: Pump features](#), (10)) with an appropriate cord set. Refer to [Table: Recommended cord sets](#).

The pump must be grounded through the conductor of the mains input connector.

4.6 Connection for remote control and monitoring

To operate the pump with parallel or serial control, the 15-way D-type connector must be used ([Figure: nXRi pumps](#), (8)).

Refer to [Figure: Logic interface connections - analogue speed control](#) for details of the logic interface pins.

The pump is also equipped with a front USB port for service purposes using serial communication. This connector cannot be used for pump operation, but for setting and reading parameters and for pump monitoring.

5. Commission the pump

To commission the pump:

1. Make sure that the voltage selection is set to correct value required for the application. Refer to [Figure: Voltage selection plate](#).
2. Make sure that all openings to atmospheric pressure in the foreline vacuum system are closed.
3. Connect the power cord.
4. Set the mains circuit breaker ([Figure: nXRi pumps, \(8\)](#)) to ON. Make sure that the power indicator LED ([Figure: Interface control panel, \(14\)](#)) illuminates. If the LED does not illuminate, contact us.
5. Press the start button ([Figure: Interface control panel, \(1\)](#)) until the run indicator LED ([Figure: Interface control panel, \(13\)](#)) begins to flash.
6. When the dry pumping system starts and continues to operate, if an alarm condition is indicated:
 - a. shut down the dry pumping system. Refer to [Shut down the pump](#) on page 35.
 - b. refer to [Fault finding](#) on page 42
 - c. if the problem has not been rectified, contact us.
7. After you commission the dry pumping system:
 - a. to continue to operate the system, refer to [Start the pump](#) on page 34.
 - b. to shut down the system, refer to [Shut down the pump](#) on page 35.

6. Operation

6.1 Operation safety



WARNING: DAMAGED PARTS

Risk of electric shock. Do not operate the pump with any parts of the enclosures removed or damaged as there may be a risk of an electric shock.



WARNING: OPERATIONAL SAFETY

Risk of injury or death of people. Do not expose any part of the human body to the vacuum as this could result in injury or death of people.



CAUTION: PUMP TEMPERATURE

Risk of injury. Do not touch the pump inlet manifold or exhaust when the pump is running as the temperatures of these parts could be high. The pump will be warm for some time after the pump has stopped.



CAUTION: AUTOMATIC START

Risk of injury or damage to equipment. The system has an auto-run mode which, if configured, is designed to automatically start the pump system once power is applied.



CAUTION: CONDENSATE DEPOSITION

Risk of damage to equipment. Do not use the pump to pump particulates or condensate. Deposition may occur within the pump which can degrade the pump performance and reduce the pump life.



CAUTION: HIGH NOISE LEVEL

Risk of hearing damage. If the pump is operated with its inlet open to atmospheric pressure, the noise generated by gas flowing into the pump can be high and exceed 85 dB(A). Continuous operation with the inlet exposed is not within the normal operating conditions of the vacuum pump.

Note:

The control interface is determined by the interface that starts the pump. Once started, the pump can only be stopped by the interface that it was started from, except in auto-run mode. In auto-run mode, the stop button on the user interface panel will override the signal and stop the pump.

 **Note:**

This is an industrial (Class B, Group 1) product as defined by EN55011 and EN61326 in compliance with European Electromagnetic Compatibility (EMC) requirements for EMC emissions. "Group 1" is defined as equipment which does not use RF energy as an intrinsic part of operation or process.

6.2 Operational modes

The pump can be controlled by:

- Manual control mode – with the buttons on the user interface panel.
- Parallel control mode – through the 15-way D-type logic interface connector located on the rear of the pump.
- Serial control mode – through the 15-way D-type logic interface connector located on the rear of the pump.
- Auto-run.

6.2.1 Manual control mode

Refer to [Figure: Interface control panel](#) for the pump control functions.

Table 11 Manual control mode

Operation	Button	Status
Apply power	Mains power	The pump will remain off (factory default). The power indicator will illuminate.
Start the pump	Start button	The pump will accelerate up to full running speed. The run indicator will flash while the pump accelerates. The run indicator will remain on when the pump reaches full speed.
Select and de-select the standby speed	Standby mode select button	When engaged, the standby indicator will illuminate and the pump will run at the standby speed setting. The pump is set by default at 70% of full speed.
Increase or decrease the pump speed when in standby mode	Standby speed increase button	The pump speed will increase. The increase standby indicator will remain illuminated when the pump reaches a maximum of 100% of full speed.
	Standby speed decrease button	The pump speed will decrease. The decrease standby indicator will remain illuminated when the pump reaches a minimum of 50% of full speed.
Select and de-select the Auto-run function	Start or stop button (>8 sec)	When engaged, the auto-run indicator will illuminate. The pump will restart automatically after the power has been restored.

Start and stop

Use the buttons ([Figure: Interface control pane](#)) to start and stop the pump.

Note:

The stop command does not isolate the pump from the electrical supply.

Standby

In standby mode the pump operates at a reduced speed to improve the service life of the pump.

1. Push the standby button to select standby mode. The pump will initially run at factory default standby speed (70% of full speed).
2. Adjust the speed with the increase and decrease standby speed buttons. The maximum standby speed is 100% of the default run speed and the minimum standby speed is 50% of the default run speed.
A single short push will change the speed by 1% of the default run speed. Hold the button to change the speed by 1% per second.
3. Once adjusted, the pump will return to the new user defined speed each time standby speed is selected.
4. Push the standby button to return to normal run speed.

Soft start and soft stop modes

For most pumps operating under normal laboratory conditions or at ultimate pressure the soft-stop mode or soft-start mode is unlikely to be invoked.

Soft stop:

If the pump is operating within a high ambient temperature the product may enter a soft-stop mode when the off command is sent or stop button is pressed, this protects the product mechanism during the shutdown procedure by enabling the pump to relax back into its stopped state. The soft-stop mode is likely to be activated in ambient temperatures higher than 30 °C. During the soft-stop mode the pump speed is halved and the cooling fan speed is increased to enable controlled cooling of the mechanism. Once a pre-defined temperature level has been met the pump will switch off completely and is then ready for restart.

The soft-stop cool down time period is expected to be < 1 minute in the majority of cases, but could last up to 4minutes depending upon the ambient temperature and load applied to the pump.

Once the soft-stop process has been activated the pump cannot be restarted until the shutdown is complete.

Soft start:

If the internal pump temperature is above a pre-defined threshold, the pump can not start immediately, when the start command is sent or start button is pressed. Instead, the cooling fan will switch on at full speed to cool the pump and once temperatures are sufficiently low the pump will run up to full speed as normal. The delay to start is expected to be < 1 minute in the majority of cases but may last longer depending upon the ambient temperature of the cooling air and the initial temperature of the pump module.

The soft-start mode can be invoked following a power outage or disconnection of power from the pump.

Table 12 LED indicators

Refer to [Figure: Interface control panel](#) for LED locations on the pump dashboard.

Description	Function
Power indicator	Indicates that electrical mains supply to the pump is ON.
Run indicator	Indicates that the pump is running.
<ul style="list-style-type: none"> ▪ LED continuously ON 	<ul style="list-style-type: none"> ▪ Pump runs at full speed
<ul style="list-style-type: none"> ▪ LED flashing 	<ul style="list-style-type: none"> ▪ When changing speed
<ul style="list-style-type: none"> ▪ LED OFF 	<ul style="list-style-type: none"> ▪ Pump is not running
Standby mode indicator	Indicates that the standby mode has been selected.
Standby speed increase indicator	The indicator will blink with every short push of the standby speed increase button. The indicator will remain ON when maximum standby speed has been reached.
Standby speed decrease indicator	The indicator will blink with every short push of the standby speed decrease button. The indicator will remain ON when minimum standby speed has been reached.
Auto-run indicator	Indicates that the auto-run mode has been selected.
Standby indicator LED	Once the standby function is selected the run indicator will flash at 50% duty while the rotational speed is changed. Once steady state running speed has been reached both the run speed and standby indicators will be illuminated.
Service indicator	Indicates that a service interval has been reached.
Alarm indicator	Indicates an alarm has been triggered.

6.3 Logic interface data

The pumps have a 15-way D-type logic interface connector located on the user interface panel ([Figure: nXRi pumps](#), (6)). The logic interface connector can be plugged directly into the 200 W Turbo Instrument Controller (TIC) with an nXRi TIC cable and in conjunction with controller extension cables.

For Turbo controller, or Turbo and Active Gauge controller (TAG), a suitable connector mating half must be used (not supplied) to connect the nXRi pump to the customer control system. Refer to and [Table: Logic interface pins](#) for the electrical connections.

Table 13 Interface technical data

Connector*	15-way D-type (male)
Start, serial enable and remote enable:	
<ul style="list-style-type: none"> ▪ Enable control voltage: low (closed) ▪ Disable control voltage: high (open) 	<ul style="list-style-type: none"> ▪ 0 to 0.8 V d.c. ($I_{OUT} = 0.55$ mA nominal) ▪ 4 to 26.4 V d.c. (internal pull-up to a Thevenin equivalent circuit: 5.3 V and 11 kOhms nominal)

Standby control input:	
<ul style="list-style-type: none"> ▪ Enable control voltage: low (closed) ▪ Disable control voltage: high (open) 	<ul style="list-style-type: none"> ▪ 0 to 0.8 V d.c. ($I_{OUT} = 0.3$ mA nominal) ▪ 4 to 26.4 V d.c. (internal pull-up to a Thevenin equivalent circuit: 2.5 V and 10.3 kOhms nominal)
Analogue and RS485 enable control inputs:	
<ul style="list-style-type: none"> ▪ Enable control voltage: low (closed) ▪ Disable control voltage: high (open) 	<ul style="list-style-type: none"> ▪ 0 to 0.8 V d.c. ($I_{OUT} = 0.55$ mA nominal) ▪ 4 to 26.4 V d.c. (internal pull-up to a Thevenin equivalent circuit: 5.5 V and 11.4 kOhms nominal)
Analogue speed input	0 to 10 V d.c. directly proportional to the motor speed e.g. 0 V = 0 Hz, 10 V = 250 Hz
Voltage accuracy	$\pm 5\%$ full scale
NORMAL status output:	
<ul style="list-style-type: none"> ▪ Type ▪ < Normal speed (default 80%) ▪ >Normal speed ▪ Maximum current rating ▪ Maximum voltage rating 	<ul style="list-style-type: none"> ▪ Open collector transistor plus pull up resistor ▪ OFF (4.7 k pull up + diode to 12 V d.c.) ▪ ON (< 0.8 V d.c. sinking 10 mA) ▪ 10 mA ▪ 28.8 V d.c.
FAIL status output:	
<ul style="list-style-type: none"> ▪ Type ▪ Fail ▪ OK ▪ Maximum current rating ▪ Maximum voltage rating 	<ul style="list-style-type: none"> ▪ Open collector transistor plus pull up resistor ▪ OFF (4.7 k pull up + diode to 12 V d.c.) ▪ ON (< 0.8 V d.c. sinking 10 mA) ▪ 10 mA ▪ 28.8 V d.c.
Analogue 10 V reference	+ 10 V d.c. analogue voltage reference unipolar output with diode protection
Voltage accuracy output	$\pm 2\%$ full scale
Current	≤ 5 mA for specified accuracy

* Mating half of connector not supplied

Table 14 Logic interface pins

Pin number	Signal	Polarity	Use
1	Analogue speed enable-control input	-	Connect to pin 2 (0 V) to enable analogue speed control via pin 9.
2	0 V control reference	-	0 V reference for all control and status signals listed within this table.
3	Start/Stop – control input	-	Connect to pin 2 (0 V) to start the pump system.

Pin number	Signal	Polarity	Use
4	Standby – control input/serial-RX/RS-485 A-	-	Connect to pin 2 (0 V) to enable standby speed when the serial enable control input is inactive.
5	Serial enable – control input	-	Connect to pin 2 (0 V) to enable serial communications.
6	RS-232/RS-485 – control input	-	Default configuration is RS-232 with pin 6 disconnected. Connect to pin 2 (0 V) to enable RS-485 serial communications.
7	Fail – status output/Serial-TX/RS-485 B+	-	Logic high when a fail/fault condition exists and the serial enable control input is inactive.
8	0 V control reference	-	0 V reference for all control and status signals listed within this table.
9	Analogue speed – control input	-	0-10 V analogue input: 0 V = 0% speed; +10 V = 100% speed
10	Chassis/Screen	-	Screen
11	+10 V analogue reference – Control output	Positive	+10 V analogue voltage reference output: 5 mA; unipolar output, diode protected.
12	Chassis/Screen	-	Screen
13	Not connected	-	Unused control pin
14	Remote – control input	-	Connect to pin 2 (0 V) to enable remote control via parallel or serial control modes.
15	Normal – status output	-	Logic low when the pump rotational speed is at normal speed or above.

6.4 Parallel control and monitoring



CAUTION: EMF RISK


Risk of damage to equipment. If you use the normal and fail lines to drive the coils of d.c. relays, include a back EMF suppression diode in parallel with each relay coil to protect the pump.

Connect the control equipment to the control input pins of the logic interface mating half. Refer to [Table: Logic interface pins](#) to identify the logic interface connector pins. The control inputs are:

- Start
 - Standby speed
 - Analogue speed
- A. To activate the control inputs, connect the relevant control input (pin 14) to the 0 V control reference.

- B. The NORMAL output can go down up to 100 mA when you control an external relay coil with an external coil voltage of + 24 V d.c. The external + 24 V voltage source, must be referenced to the common control voltage of the pump control system, i.e. pin 2 of the 15-Way D-Type customer interface connector. Alternatively, if the NORMAL output is connected to + 10 V reference output of the control system, i.e. pin 11 of the 15-Way D-Type connector, a 4.7 kOhm pull-up resistor is recommended to be kept in the current rating of + 10 V reference rail.
- C. The FAIL output can go down up to 100 mA when you control an external relay coil with an external coil voltage of + 24 V d.c. The external + 24 V voltage source, must be referenced to the common control voltage of the pump control system, i.e. pin 2 of the 15-Way D-Type customer interface connector. Alternatively, if the FAIL output is connected to + 10 V reference output of the control system, i.e. pin 11 of the 15-Way D-Type connector, a 4.7 kOhm pull-up resistor is recommended to be kept in the current rating of + 10 V reference rail.


Figure 13 Logic interface connections - parallel control



6.5 Analogue speed control


The analogue speed input is a process control source which enables the pump to run at variable operating speeds. This speed control source is an alternative to standby speed control.

Figure 14 Logic interface connections - analogue speed control



- 1. Analogue control switch
- 2. Start switch
- 3. nXRi pump logic interface

Figure 15 Analogue speed control



- 1. Upper speed clamp - Maximum standby setting = 250 Hz
- 2. Lower speed clamp - Minimum standby speed setting = 125 Hz
- 3. Active speed range - 50.00 % to 100.00 %
- 4. Active Voltage range - 5.00 V to 10.00 V (125Hz to 250 Hz)

Note:

0.1 V = 1% of default run speed.
 Voltages below 5 V will result in a clamped speed of 50% of full speed.

6.6 Hardware configuration

Use the 15-way D-type connector (*Figure: Pump features*, (6)) and configure the signal to enable the analogue speed control source:

- Connect the analogue speed enable control input (pin 1) to the 0 V control reference (pin 2).
- Connect a suitably calibrated analogue voltage source (0 to +10 V), for example, (DAC) to the analogue speed control input (pin 9).
As an alternative, connect the output of a potentiometer referenced to the pump reference voltage (pin 11) to the analogue speed control input (pin 9). Refer to *Figure: Logic interface connections - analogue speed control*. The 0 V rail of the external voltage source must be connected to the 0 V control reference (pin 2) of the pump controller.

6.7 Operational modes

- A +10 V input results in a mechanical running speed which is equal to 100% of the default run speed, that is 250 Hz.
- The minimum running speed provided by the analogue speed control source, is clamped at the minimum standby speed setting (approximately 50% of the default run speed).
- The maximum running speed provided by the analogue speed control source is clamped by the maximum standby speed setting (100% of the default run speed).

6.8 Start the pump



WARNING: EXHAUST PIPELINE BLOCKAGE

Risk of damage to equipment. Do not operate the pump if the exhaust pipeline is restricted or blocked as the pump will not operate correctly and may be damaged.

To start the pump:

1. Make sure that the vacuum system isolation valve is closed (if fitted).
2. Make sure that the mains supply to the pump is isolated.
3. Connect a recommended lead to the electrical socket on the pump. Refer to *Figure: Pump features*.
4. Supply the power.
5. Start the pump with the applicable control source that follows:
 - use the start button in manual control mode, refer to *Figure: Interface control panel*
 - use the start/stop control input in parallel control mode
 - use start command in serial control mode
6. Open the vacuum system isolation valve, if installed.

6.9 Shut down the pump



CAUTION: PUMP SUPPLY ISOLATION

Risk of injury. Do not remove the inlet connections until the pump has been allowed to stop rotating and the power and gas supply has been isolated. The pump can take up to three minutes to stop completely.



WARNING: ELECTRICAL SUPPLY

Risk of damage to equipment. Do not disconnect the pump from the electrical supply until the pump has stopped completely.

The pump can be shut down with either the front panel controls or the 15-way D-type connector in either parallel or serial control mode.

Note:

If the pump is to be shut down for storage, remove any process gases by running on a gas ballast for at least one hour.

To shut down the pump:

1. Close the gas ballast.
2. Close the vacuum system isolation valves to prevent suck-back into the vacuum system (where fitted).
3. Stop the pump system with the appropriate control source.
 - use the stop button in manual control mode, refer to [Figure: Interface control panel](#).
 - use the start/stop control input in parallel control mode.
 - use stop command in serial control mode.
4. Isolate the mains supply.

If the pump is to be stored, we recommend you either keep the pump under vacuum or fill the pump with dry nitrogen to prevent condensation in the pump. To keep the pump under vacuum, we recommend you seal the inlet and run the pump for at least 20 seconds.

6.10 Restart the pump

If the pump is automatically shut down because of an alarm condition, correct the alarm condition before you start the pump. To restart the pump, refer to [Start the pump](#) on page 34.

If water vapor is present within the system, or will be pumped by the product the gas ballast must be used to prevent damage to the product. The gas ballast should continue to be applied with the pump running, for at least 1 hour after the water vapor source has been removed to enable the pump to dry.

6.11 Unplanned shutdown

Allow the pump to cool after a sudden power outage, for example, due to power cut, circuit breaker trip or if the power cord is removed accidentally. We recommend a minimum of one minute to cool the pump, more time is required if the pump is working with a high load or high ambient temperature.


If the pump is configured for auto-restart, the pump may trip due to over-current if the power cut is less than 7 seconds. A longer cooling period is required to reset the pump. Disconnect the power supply for one minute and then reconnect it. If an error occurs, refer to [Fault finding](#) on page 42.

6.12 Gas ballast operation


Gas ballast is operated by a black plastic knob that may be positioned to either position 0 (which means the gas ballast is closed), position 1, or any other elevated rim result that feeds air to the pumping mechanism with a flow of approximately 25 slm.

If water vapor is present within the system, or will be pumped by the product the gas ballast must be used to prevent damage to the product. The gas ballast should continue to be applied with the pump running, for at least 1 hour after the water vapor source has been removed to enable the pump to dry.

Figure 16 Gas ballast open-close



6.13 Gas ballast adaptor fit



The manually operated gas ballast knob can be replaced by a gas ballast adaptor which enables external electrically actuated valves or a controlled gas supply to be used through a 1/4 inch push fit connector. To install the gas ballast adaptor:


1. The gas ballast knob must be pulled out from gas ballast spindle by flat headed screwdriver or any similar tool can be used to lever the fitting free. To help position the tool underneath the knob it may be necessary to partially rotate the knob in-between notches.
2. Once the GB knob has been removed the internal valve can be extracted using an 21 mm socket wrench.
3. The adaptor can now be installed using a 21 mm socket wrench. Make sure that a clean O-ring is assembled onto the adaptor before you start installation.

6.14 Extra silencer removal

The pump is furnished by an additional removable silencer in the form of a drilled M12 plug that can be removed by allen key of size 10. Removal is advised when the exhaust of the pump is connected to additional exhaust pipeline to gain up to 2 m³/h in pumping speed from atmosphere.


6.15 Mounting kit use

A mounting frame is available as an accessory (part number A90590000). This can be used to mount the pump to a cart or bolt it to the floor. The mounting frame has two holes and two holes for M8 bolts. These are aligned with the corresponding mounting positions on Edwards leak detector carts (center slot) or turbo carts.



Installation instructions:

1. Remove two screws at the back of the pump in the pump enclosure. Store these screws in a safe position.
2. Use suitable M8 screws to mount mounting frame at the target location.
3. Lift or roll pump on the mounting frame with the pump back side aligned with the mounting frame.
4. Use included screws and washers to fix pump to mounting frame.



7. Maintenance and service

7.1 General maintenance

The system requires no user maintenance. Maintenance must be done by trained personnel. The frequency of the maintenance depends on the process and can be adjusted according to the user experience. Refer to [Maintenance plan](#) on page 39 for the maintenance schedule.

We recommend a monthly visual inspection of the dry pump system. Check that the electrical supply cord, hoses and pipelines connected to the pump are in good condition and are secured properly.

7.2 Maintenance plan

More frequent maintenance may be required if the pump is used to pump aggressive gases or vapours, solvents, organic substances and acids, or if the pump is operated continuously at high operating temperature.

Table 15 Maintenance plan

Operation	Frequency (months)	Service indicator	Reference
Inspect and clean the inlet strainer	12	No	Inspect and clean the inlet strainer on page 39
Inspect and clean the external fan cover if required	12	No	Clean the external fan grill on page 40
Replace the pump bearings	60	Yes	Replace the pump bearings on page 40
Replace the pump controller	120	Yes	Replace the pump controller on page 40
Electrical safety check	60	No	Electrical safety check on page 40

 **Note:**

The pump must be returned to the Service Technology Centre for maintenance. For service indicator codes, refer to [Table: Service indicator codes](#).

7.3 Inspect and clean the inlet strainer

Whenever the pump is disconnected from the vacuum system or annually:

- Remove the inlet strainer from the pump inlet, refer to [Figure: Pump features](#).
- Clean the pump inlet and remove the debris that may have accumulated.
- Examine the inlet strainer and if necessary, clean it with a cleaning solution suitable for the substances pumped.
- Install the inlet strainer before you reconnect the pump to the vacuum system. Refer to [Mechanical installation](#) on page 20.

7.4 Clean the external fan grill

If the fan cover is not kept clean, the air flow over the pump can be restricted and the pump may overheat.

To clean the fan grill:

1. Switch off the pump and disconnect from the electrical supply.
2. Use a dry cloth and a soft brush to remove dirt and deposits on the fan cover.

7.5 Replace the pump bearings

The service indicator, (flashing ON 3 sec/OFF 1 sec) is activated to indicate that a bearing replacement service interval has been reached. Bearing wear cannot always be detected under normal operating conditions. This service interval is a recommendation that a bearing replacement is required and is useful in the preventative maintenance plan.

 **Note:**

Failure to replace the pump bearings on time can damage the pumping mechanism.

To reset the service indicator, refer to [Table: Service indicator codes](#).

Bearing replacement is not possible by the customer, the pump must be returned to a Service Technology Centre for maintenance.

7.6 Replace the pump controller

The service indicator, (flashing ON 3s / OFF 3s) is activated to indicate that the pump controller must be replaced. Contact us for further details.

To reset the service indicator, refer to [Table: Service indicator codes](#).

Controller replacement is not possible by the customer, the pump must be returned to a Service Technology Centre for maintenance.

7.7 Electrical safety check

Test the earth continuity and the insulation resistance of the pump system in accordance with local regulations for the periodic test of electrical equipment.

The earth continuity must be less than 0.1 Ω and the DC insulation resistance greater than 1.0 M Ω . If the pump fails any of these tests, contact us or the supplier.

7.8 Service indicator codes

The pump controller has a service indicator, refer to [Figure: Interface control panel](#). The service indicator will flash a specific code whenever a service interval is reached. See [Table: Service indicator codes](#) for service levels.

Table 16 Service indicator codes

Service flash code	Comments
ON 3s/OFF 1s	Pump bearing service
ON 3s/OFF 3s	Pump controller service

7.9 Service

It is recommended that the pump should be serviced every 5 years. The pump should then be returned to an Edwards Service Technology Centre.

Our products are supported by a world-wide network of Service Technology Centres offering a wide range of options including:

- Complete remanufacturing (includes 6 months warranty)
- Exchange pump (includes 12 months warranty)

Both services include decontamination, repair, rebuild and test to factory specification.

A local Service Technology Centre can also provide trained engineers to support the exchange pump option. For more information about service options, contact us or the nearest Service Centre.

7.9.1 Return the equipment or components for service

Before you send your equipment to us for service or for any other reason, you must send us a completed Declaration of Contamination of Vacuum Equipment and Components – Form HS2. The HS2 form tells us if any substances found in the equipment are hazardous, which is important for the safety of our employees and all other people involved in the service of your equipment. The hazard information also lets us select the correct procedures to service your equipment.

We provide instructions for completing the form in the Declaration of Contamination of Vacuum equipment and Components – Procedure HS1.

If you are returning a vacuum pump, note the following:

- If a pump is configured to suit the application, make a record of the configuration before returning the pump. All replacement pumps will be supplied with default factory settings.
- Do not return a pump with accessories fitted. Remove all accessories and retain them for future use.
- The instruction in the returns procedure to drain all fluids does not apply to the lubricant in pump oil reservoirs.

Download the latest documents from edwardsvacuum.com/HSForms/, follow the procedure in HS1, fill in the electronic HS2 form, print it, sign it, and return the signed copy to us.



NOTICE:

If we do not receive a completed HS2 form, your equipment cannot be serviced.

Note:

Do not take the enclosure off, the pump must be returned to a Service Technology Centre for maintenance

8. Fault finding

A list of fault conditions and their possible causes is provided to assist in basic troubleshooting. If you are not able to rectify a fault, call your supplier or your nearest Service Technology Centre for advice.

Fault	The pump has failed to achieve the required performance
Cause	The vacuum fittings are dirty or damaged.
Remedy	Make sure that the vacuum fittings are clean and scratch free.
Cause	There is a blockage or high pressure in the exhaust line.
Remedy	Make sure that the exhaust valves fitted are not closed when the pump is in operation.
Cause	The motor controller is current limiting the supply.
Remedy	If the alarm indicator LED (<i>Figure: Interface control panel</i> , (5)) flashes, it indicates that the pump has high current load from possibly a high inlet pressure/flow. Adjust the inlet pressure/flow until the pump performance recovers.
Cause	The pump performance is different at the working application load.
Remedy	The pump does not have a flat performance curve, peak pumping speed can vary with inlet pressure and gas load. Check the actual performance against the performance curve shown in <i>Technical data</i> on page 13.
Cause	Blocked rotors
Remedy	When the pump gets hot and if debris may have been ingested or condensed within the pump, the rotors may be stuck. Let the pump cool down to room temperature, then restart, once operational run the pump with the gas ballast applied for at least 2 hours to try and clear any internal blockages. If the problem persists is recommended to contact supplier for further information and advice.
Cause	The pressure measurement technique or gauge head is not suitable or gives an incorrect indication of pressure.
Remedy	Make sure that the vacuum measurement equipment is calibrated and is updated. The correct gauge range must be selected for the application. Contact us for further assistance on gauge selection, if required.
Fault	The pump is noisy
Cause	The pump is contaminated with solid particles.
Remedy	Contact us or the supplier for further information.
Fault	The pumping speed is poor or pump down time is too long
Cause	The pipelines connections are too small in diameter.
Remedy	Make sure that the pipework has sufficient conductance (user's responsibility) and the pump performance is not compromised.

Cause	There is a leak in the system.
Remedy	Do the leak test of the pump system in accordance with the requirements specified in Table: Performance data .
Cause	The motor controller is current limiting the supply.
Remedy	Adjust the inlet pressure/flow until the pump performance recovers.
Cause	The pump chamber is too big (nXR120i only).
Remedy	Make sure that the chamber size does not exceed the limits specified in Table: Mechanical data .

8.1 Alarm indicator codes

When the fail condition becomes active, the red alarm indicator shows a flashing sequence.

- If the error light is on continuously, this indicates a problem has been found with the embedded software. In this case, switch the power supply on and off.
- If the indication is not cleared, a software download may be required. In this case, contact us or the supplier.
- If the alarm indicator is flashing, identify the error flash code. Refer to [Table: Flashing error codes](#).

 **Note:**

There is a sufficient off period between each subsequent cycle repetition to mark the start of a new flash sequence. The duration of a long flash (L) is equal to 3 times the duration of a short flash (0.5 s).

Table 17 Flashing error codes

Error flash position	Error flash sequence	Comment	Actions
0	S-S-S-S-S	Overload timeout	Check if the pump is not under constant high pressure or the inlet or outlet is not blocked.
1	L-S-S-S-S	Controller software error	Switch the power to the pump off and on and see whether the error code appears again. If it does, contact us or the supplier.
2	S-L-S-S-S	Controller failed internal configuration and calibration operation	Switch the power to the pump off and on and see whether the error code appears again. If it does, contact us or the supplier.
3	S-S-L-S-S	Acceleration timeout	Check if the pump is under constant high pressure or the inlet or outlet is blocked.
4	S-S-S-L-S	Over-current trip activated, or other hardware fault	Switch power to the pump off and on and see whether the error code appears again. If it does, contact us or the supplier.

Error flash position	Error flash sequence	Comment	Actions
5	s-s-s-s-L-s	Self test fault	Switch the power to the pump off and on and see whether the error code appears again. If it does, contact us or the supplier.
6	s-s-s-s-L	Serial control mode interlock	Re-activate the serial enable and send a serial command to clear the error code.

9. Storage



WARNING: INHALATION HAZARD

Risk of asphyxiation. Do not burn the fluoroelastomer seals and O-rings.



CAUTION: LUBRICATION TRANSFER

Risk of damage to equipment. Install blanking plates to seal the vacuum inlet and outlet port. The pumps must be stored in a horizontal configuration to prevent possible lubrication transfer.

To store the pump:

1. Shut down the pump. Refer to [Shut down the pump](#) on page 35.
2. Disconnect the pump from the electrical supply.
3. Place and secure protective covers over the inlet and outlet ports.
4. Store the pump in a clean and dry condition until required for use.
5. When necessary, prepare and install the pump. Refer to [Installation](#) on page 19.

10. Disposal



WARNING: CONTAMINATION HAZARD

Risk of toxic exposure and acid burns. Identify, contain and safely dispose of contaminated items.

Dispose of the pump and any components or accessories safely and in accordance with all local and national safety and environmental requirements.

Our products are supported by a world-wide network of Service Centres. Each Service Centre offers a wide range of options including disposal. Refer to [Service](#) on page 41 for more information.

Dry pump system materials suitable for recycling include cast iron, steel, PTFE, stainless steel, aluminium, zinc alloy, nickel, mild steel, ABS and polyamide.

Take particular care with:

- Fluoroelastomers which may have decomposed as the result of being subjected to high temperatures.
- Components which have been contaminated with dangerous process substances.

11. Accessories

Contact us for information on the available accessories to support your pump.

11.1 Electrical cables

Table 18 Recommended cord sets

Description	Rating	Coupler type	Item number
Cord set assembly, UK	Black H05VV-F, 3 x 1.5 mm ² , 300 V, 70 °C fitted with an BS1363 UK plug with BS1362 13 A fuse to an IEC60320 style C19 with a maximum length of 2.5 m	Straight entry	A50505003
Cord set assembly, Europe	Black H05VV-F, 3 x 1.5 mm ² , 300 V, 70 °C fitted with an European Schuko VDE approved 16 A 250 V rated plug with dual earthing contact to an IEC60320 style C19 with a maximum length of 2.5 m		A50506003
Cord set assembly, USA/Canada (200-240 V)	Black SJT, 3 x 14 AWG, 300 V, 90 °C, VW-1 fitted with an NEMA 6-15P plug and IEC60320 C19 coupler with a maximum length of 2 m		A50507006
North America 115 V	Black SJT, 3 x 18 AWG/0.75 mm ² , 250 VAC, -25 °C to +70 °C ,V-2 fitted with a NEMA 5-15P plug		A50507003
Cord set assembly with no plug 20 A	Black H05VV-F, 3 x 1.5 mm ² , 300 V, 70 °C fitted with an IEC 60320 C19 coupler and no plug with a minimum length of 2.5 m		A50508003
Cord set assembly, China	Black H05VV-F, 3 x 1.5 mm ² , 300 V, 70 °C fitted IEC 60320 C19 coupler and China GB2099 plug		A50509003

Table 19 Cables

Description	Item number
USB Interface Cable	D39801810
nXRi TIC Cable	D39803014
Controller Extension Cable 1m	D39700835
Controller Extension Cable 2m	D39700836
Controller Extension Cable 5m	D39700837

11.2 Gas ballast adaptor

Table 20 Gas ballast adaptor

Description	Item number
Gas ballast adaptor with fine restrictor	A73501809
Gas ballast adaptor without fine restrictor	A73501811

11.3 Gas ballast blank adaptor

Table 21 Gas ballast blank adaptor

Description	Item number
Gas ballast blank adaptor	A73501806

11.4 Valves

Table 22 Valves

Description	Item number
VIV40EKA 24 V d.c. - Vacuum isolation valve with 24 V DC control	A50637510
VIV LINK M8 Connector to valve - Enables the connection between VIV valve and the pump through M8 connector.	A50637399

11.5 Mounting kit

Table 23 Mounting kit

Description	Item number
Mounting kit for cart/floor	A90590000

EU Declaration of Conformity

**Edwards Ltd**

Innovation Drive
Burgess Hill
West Sussex
RH15 9TW
UK

Documentation Officer

Jana Sigmunda 300
Lutín , 78349
Czech Republic
T: +42(0) 580 582 728
documentation@edwardsvacuum.com

The product specified and listed below

nXR30i 100-127/200-240V 1ph 50/60 Hz NW25 Inlet	A 903 01 983
nXR40i 100-127/200-240V 1ph 50/60 Hz NW25 Inlet	A 904 01 983
nXR60i 100-127/200-240V 1ph 50/60 Hz NW40 Inlet	A 905 02 983
nXR90i 100-127/200-240V 1ph 50/60 Hz NW40 Inlet	A 906 02 983
nXR120i 100-127/200-240V 1ph 50/60 Hz NW40 Inlet	A 907 02 983

Is in conformity with the relevant requirements of European CE legislation:

2006/42/EC	Machinery directive <i>Note: The safety objectives of the Low Voltage Directive 2014/35/EU were complied with in accordance with Annex 1 No. 1.5.1 of this directive.</i>
2014/30/EU	Electromagnetic compatibility (EMC) directive Class B Emissions, Class A Industrial Immunity
2011/65/EU	Restriction of certain hazardous substances (RoHS) directive as amended by Delegated Directive (EU) 2015/863

Based on the relevant requirements of harmonised standards:

EN ISO 12100:2010	Safety of machinery. General principles for design. Risk assessment and risk reduction
EN 1012-2:1996 +A1:2009	Compressors and vacuum pumps. Safety requirements. Vacuum pumps
EN 61326-1:2013	Electrical equipment for measurement, control and laboratory use. EMC requirements. General requirements

This declaration, based on the requirements of the listed Directives and EN ISO/IEC 17050-1, covers all product serial numbers from this date on: *2022-04-29*

You must retain the signed legal declaration for future reference

This declaration becomes invalid if modifications are made to the product without prior agreement.



*Petr Šmerek – Engineering Manager
Scientific Vacuum Division, Lutín*



*Jan Večeřa – General Manager
Lutín, CZ*

Declaration of Conformity

Edwards Ltd
Innovation Drive
Burgess Hill
West Sussex
RH15 9TW
UK

Documentation Officer
documentation@edwardsvacuum.com

This declaration of conformity is issued under the sole responsibility of the manufacturer.

nXR30i 100-127/200-240V 1ph 50/60 Hz NW25 Inlet	A 903 01 983
nXR40i 100-127/200-240V 1ph 50/60 Hz NW25 Inlet	A 904 01 983
nXR60i 100-127/200-240V 1ph 50/60 Hz NW40 Inlet	A 905 02 983
nXR90i 100-127/200-240V 1ph 50/60 Hz NW40 Inlet	A 906 02 983
nXR120i 100-127/200-240V 1ph 50/60 Hz NW40 Inlet	A 907 02 983

The object of the declaration described above is in conformity with relevant statutory requirements:

Supply of Machinery (Safety) Regulations 2008

The objectives of the Electrical Equipment (Safety) Regulations 2016 are governed by Annex 1 1.5.1 of this regulation.

Electromagnetic Compatibility Regulations 2016

Class B Emissions, Class A Industrial Immunity

Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

Relevant designated standards or technical specifications are as follows:

EN ISO 12100:2010	Safety of machinery. General principles for design. Risk assessment and risk reduction
EN 1012-2:1996 +A1:2009	Compressors and vacuum pumps. Safety requirements. Vacuum pumps
EN 61326-1:2013	Electrical equipment for measurement, control and laboratory use. EMC requirements. General requirements

This declaration, based on the requirements of the listed Statutory Instruments and EN ISO/IEC 17050-1, covers all product serial numbers from this date on: 2022-04-29

You must retain the signed legal declaration for future reference

This declaration becomes invalid if modifications are made to the product without prior agreement.

Signed for and on behalf of Edwards Ltd



*Petr Šmerek – Engineering Manager
Scientific Vacuum Division, Lutín*



*Jan Večeřa – General Manager
Lutín, CZ*

ADDITIONAL LEGISLATION AND COMPLIANCE INFORMATION

EMC (EU, UK): Class B Emissions, Class A Industrial equipment

Caution: This equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.

RoHS (EU, UK): Material Exemption Information

This product is compliant with the following Exemptions

Annex III:

- 6(c) Copper alloy containing up to 4% **lead** by weight

REACH (EU, UK)

This product is a complex article which is not designed for intentional substance release. To the best of our knowledge the materials used comply with the requirements of REACH. The product manual provides information and instruction to ensure the safe storage, use, maintenance and disposal of the product including any substance based requirements.

Article 33.1 Declaration (EU, UK)

This product contains Candidate List Substances of Very High Concern above 0.1%ww by article as clarified under the 2015 European Court of Justice ruling in case C-106/14.

- Lead (Pb)
This substance is present in certain brass connectors.

WASTE FRAMEWORK DIRECTIVE (EU)

SCIP Number: a55a7c71-7c7d-4b43-98f5-633b620bfd61


Additional Applicable Requirements

The product is in scope for and complies with the requirements of the following:

2012/19/EU	Directive on waste electrical and electronic equipment (WEEE)
Product is certified to CSA-C22.2 No.61010-1-12	Safety requirements for electrical equipment for measurement, control and laboratory use – Part 1: General requirements
Product is certified to UL61010-1 3 rd Edition	Safety requirements for electrical equipment for measurement, control and laboratory use – Part 1: General requirements
EAC	JSC "Atlas Copco" Vashutinskoe shosse, 15, Khimki, Moscow region, Russia, 141402

材料成分声明

China Material Content Declaration

部件名称 Part name 	有害物质 Hazardous Substances					
	铅 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr VI)	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
铜接头 Brass connectors	X	0	0	0	0	0

O: 表示该有害物质在该部件的所有均质材料中的含量低于 GB/T 26572 标准规定的限量要求。

O: Indicates that the hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: 表示该有害物质在该部件的至少一种均质材料中的含量超出 GB/T26572 标准规定的限量要求。

X: Indicates that the hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T26572.

This page has been intentionally left blank.

This page has been intentionally left blank.

